

Quick Guide




R7054-V2

Security Remote Control

Version: 1.0

Product Appearance



Introduction

The security remote control is used to change your alarm system status: Away, At home, Disarm.

Away mode: away arm your home security system with security remote control.

Home mode: secure your home even when you are at home.

Disarm: disarm your alarm with security remote control quickly.

Emergency trigger: immediately activate your alarm in case of emergency.

Requirement to use


1. Tuya Smart app
2. Smart Zigbee Gateway (not included)


Installation

1. Make sure Security Remote Control is in the range of Zigbee gateway's signal.
2. Pull the insulation sheet from battery compartment of the Security Remote Control before connecting to gateway.


Set up the Security Remote Control with Tuya Smart app

1. Download and install the app "Tuya Smart" from Apple App Store or Google Play Store on your mobile device.






2. Launch the app "Tuya Smart".
3. Create a new account or log in to your existing account.
4. Tap "+" and the app will start to auto scan your device. Please noted that "Auto scan" function requires location permission for the Tuya Smart app to find the device.



5. Please also make sure at least one gateway is added in app, if you have multi gateway in the app, please select a gateway you wish to use.
6. Ensure the blue indicator light of Security Remote Control

is flashing. If the indicator light isn't flashing: press and hold the reset button for 5 seconds until the blue indicator light starts to flashing.



7. The app will now search for the device and register it to your account.
8. Enter the device name.

Support

You can find much more useful information in the Help Center in the App. You can also contact us via the Help Center Feedback in the App.

Specification

- Battery: CR2032 x 1 (included)
- Wireless connection: Zigbee 3.0
- Frequency: 2.405-2.480GHz
- Connection distance: indoor 10-30m
- Dimension: 66x34x11mm
- Working temperature: -10°C- 50°C
- Working humidity: 0-95%RH, no condensation